

OIL STRAINER



Product introduction ;


Oil strainers clear away the solid waste and the welding burrs that can cause damage in oil level regulators and compressors. They prevent all kind of dirt from going to the oil level regulator, there by minimizing the blockage risk of the oil level regulator.

Oil strainers are placed between the oil reservoir and the oil level regulator.
Oil strainers should be fixed vertically and the inlet connection should be installed upwards.



- 1 Outlet Connection
- 2 Inlet Connection

Technical Data



Model	Dimension		Connection Size		CE	
	Da (mm)	L (mm)	Inlet (Inch)	Outlet (Inch)	PED	97/23/EC
OSR-3/8s	ø51	134	3/8" SAE Flare	3/8" SAE Flare	SEP	
OSR-3/8f		141	3/8" ODS	3/8" ODS		